

MOISTURISING BASE O/W MILK


Ref.F-20/W-0087/01

TRADE NAME (INCI)	FUNCTION	SUPPLIERS	% w/w
Step 1 : dilution 1:2			
A			
Massocare MILK3 (Caprylic/capric Triglyceride, Triethylhexanoin, Glycerin, Polyperfluoroethoxymethoxy Difluoroethyl PEG Phosphate)	<i>o/w concentrated emulsion</i>	(1)	33.50
Water (Aqua)	<i>solvent</i>		66.50
Step 2 :			
A			
Dilution 1:2 up to			100.00
B			
Massocare TCK A1 (Sodium Polyacrylate, Paraffinum Liquidum, Trideceth-6)	<i>rheology modifier</i>	(1)	1.00

MOISTURISING BASE O/W MILK



Ref.F-20/W-0087/01

APPEARANCE : white milk

SPECIFICATIONS :

Viscosity : 9.550 mPa·s (Brookfield LVT , Spindle B, 12 rpm) 20°C

pH : 5.82

PROCEDURE (cold process) :

Step 1 :

1. Add water to Massocare Milk3 whilst stirring
2. Homogenise mixture for 2 minutes (Silverson: 3.000 rpm)
3. Stir for 20-30 minutes

Step 2 :

1. Add phase B to A whilst stirring moderately
2. Homogenise mixture for 2 minutes (Silverson: 3.000 rpm)
3. Adjust final pH (5.5 - 6.5), if it's necessary
3. Stir at 100-200 rpm during 30 minutes, minimum

KEY INGREDIENTS :

Massocare MILK3 - concentrated o/w emulsion for sprayables, milks and creamy-gels

Massocare TCK A1 - ready-to-use thickener and stabiliser

SUPPLIERS :

(1) Cial. Química Massó